

Bosch DS160 / DS161

Installation Guide: [Bosch-DS161-User-Manual-A1](#)

DIP Switch 1: LED Operation
DIP Switch 2:

Table 2: Relay Timer DIP Switch Settings			
Time (sec)	Switch 4	Switch 5	Switch 6
0.5 (Default)	OFF	OFF	OFF
1	OFF	OFF	ON
2	OFF	ON	OFF
4	OFF	ON	ON
8	ON	OFF	OFF
16	ON	OFF	ON
32	ON	ON	OFF
64	ON	ON	ON

Revision #1
Created 2026-02-17 11:56:41 UTC by Ryan Walsh
Updated 2026-02-17 12:01:41 UTC by Ryan Walsh